## **Table of Contents**

| Annliance installation instruction |  |
|------------------------------------|--|
| Appliance installation instruction |  |

## **Appliance installation instruction**

A typical connection diagram for **x86 server hardware**:



Cards with 10/25/40/100 network ports are placed in slots 1-10 Each slot has a unique PCle bus identifier, e.g. 02:00. Each port has a unique identifier on the card, e.g. 02:00.0, 02:00.1, 02:00.2, 02:00.3.

## **Example of interfaces orientation in pairs:**

```
# In, to the subscriber side - port 02:00.0, 02:00.2
in_dev=02:00.0|02:00.2
  # Out, to the Internet side - port 02:00.1, 02:00.3
out_dev=02:00.1|02:00.3
```

Port configuration is described in the section DPDK Interfaces Configuration.

Ports **mg0**, **mg1** are used for SSH management, IPFIX sending (Full flow, NAT log, ClickStream), integration with Radius/PCRF . For fault tolerance, they are combined in LAG.

The **bmc** port is used to connect to the BMC server controller.

Each server has two power supplies **psu1**, **psu2** for power redundancy.