Содержание

CGNAT. Network Address Translation for IPv4	3
Test 1. Configuring CGNAT and NAT 1:1 via CLI	3
1. Creating a NAT service (CLI)	. 4
2. Assigning the NAT service to a subscriber (CLI)	4
3. Creating a reverse route (CLI)	5
4. Checking traffic flow and interface orientation (CLI)	5
5. Displaying translation information (CLI)	6
Test 2. Configuring CGNAT and NAT 1:1 via GUI	6
1. Creating a NAT service (GUI)	6
2. Assigning the NAT service to a subscriber (GUI)	. 8
3. Creating a reverse route (GUI)	8
4. Checking traffic flow and interface orientation (GUI)	. 8
5. Displaying translation information (GUI)	. 9
Test 3. Configuring NAT log export to external collector and locally to file	. 9
1. Exporting NAT log to external collector	9
2. Exporting NAT log locally	9

CGNAT. Network Address Translation for IPv4

Why NAT is used in practice:

NAT technology helps conserve IPv4 address space and reduces the likelihood of devices in the operator's network being hacked. On the SSG, two modes can be configured:

- CGNAT Network Address and Port Translation allows multiple subscribers to share a single public IPv4 address, extending the usage of the limited IPv4 address space.
- NAT 1:1 One-to-one Network Address Translation assigns a public IP address to a subscriber with a private IP without changing the settings on their equipment or the terminating router.

Let's test this:

- Test 1. Configuring CGNAT and NAT 1:1 via CLI
- Test 2. Configuring CGNAT and NAT 1:1 via GUI
- Test 3. Configuring NAT log export to external collector and locally to file





Let's start testing. The actions can be performed both via the graphical interface of the SSG and through the CLI. The choice of method is up to the client; both methods are presented in the instructions.

Test 1. Configuring CGNAT and NAT 1:1 via CLI



1. Creating a NAT service (CLI)

Enter the command in the command line:

CGNAT:

fdpi_ctrl load profile --service 11 --profile.name cg_nat --profile.json '{
 "nat_ip_pool" : "10.10.10.0/24", "nat_tcp_max_sessions" : 2000,
 "nat_udp_max_sessions" : 2000 }'

NAT 1:1:

fdpi_ctrl load profile --service 11 --profile.name bi_nat --profile.json '{
 "nat_ip_pool" : "10.10.10.0/24", "nat_type": 1 }'

Command values:

- load profile creating a profile
- service 11 service number on the SSG, for the NAT service it is 11
- profile.name name of the created profile, cg_nat and bi_nat
- profile.json '{ "nat_ip_pool" : "10.10.10.0/26", "nat_tcp_max_sessions"
 - : 2000, "nat_udp_max_sessions" : 2000 }' profile settings in JSON format:
 - nat_ip_pool NAT pool subnets separated by commas. If the extreme addresses need to be excluded, you can add ~ (10.10.10.0/24~) at the end, so the pool will contain addresses from 10.10.10.10.1 to 10.10.254.
 - nat_tcp_max_sessions maximum number of TCP sessions per subscriber.
 - nat_udp_max_sessions maximum number of UDP translations per subscriber.
 - nat_type NAT operation mode. 0 for CGNAT, 1 for NAT 1:1. The default is 0, so this field is not specified for CGNAT.

2. Assigning the NAT service to a subscriber (CLI)

CGNAT

Assigning the NAT service to a subscriber is possible by IP or CIDR.

Example of assigning the service by IP:

fdpi_ctrl load --service 11 --profile.name cg_nat --ip 100.64.0.1

Example of assigning the service to the entire CIDR:

fdpi_ctrl load --service 11 --profile.name cg_nat --cidr 100.64.0.0/24

NAT 1:1

Example of assigning the service by IP:

fdpi_ctrl load --service 11 --profile.name bi_nat --ip 100.64.0.1

Example of assigning the service to the entire CIDR:

```
fdpi_ctrl load --service 11 --profile.name bi_nat --cidr 100.64.0.0/24
```

These commands are enough to configure NAT on the SSG. The SSG by default operates in bridge mode, meaning it creates NAT translations and forwards traffic in both directions but does not participate in routing.

3. Creating a reverse route (CLI)

To route reverse traffic to the NAT pool towards the subscribers, it will be necessary to create a route to the NAT pool on the router after the SSG and make this route known to the other routers in the network.

Consider a situation where a point-to-point network 10.0.1.0/30 is configured between the routers with the SSG, the router's interface on the subscriber side (R1) has the IP 10.0.1.2, and the router's interface after the SSG (R2) has the IP 10.0.1.1 (see the diagram).



On router R2, it will be necessary to configure the route to the NAT pool. For Cisco-like CLI, the configuration will look like this:

```
conf t
ip route 10.10.10.0 255.255.255.192 10.0.1.2
```

It will also be necessary to configure the redistribution of static routes so that the route is known not only to R2 but also to the rest of the network. If OSPF is used:

```
router ospf 1
redistribute static subnets metric-type 1
```

Where 1 in router ospf 1 is the OSPF process number on the router.

4. Checking traffic flow and interface orientation (CLI)

From the test PC, check the application of NAT:

- Check the availability of router R2.
- Run the command ping 10.0.1.2. If R2 is unavailable, check the orientation of the SSG

interfaces.

The In interface connects the subscribers, the Out interface connects to the internet. Determine which interface is which by setting the port connected to the SSG to down on R1 and outputting the status of interfaces on the SSG.

```
fdpi_cli dev xstat|grep --no-group-separator -B1 "Link status"|paste - |sort
Device 02:00.0: Link status: link down
Device 02:00.1: Link status: link up
```

Check the configuration in fastdpi.conf If necessary, change the direction and restart the service with the command

service fastdpi restart

5. Displaying translation information (CLI)

For each IP, it is possible to display the current state of the NAT service.

View the number of active sessions and the assigned public address for a specific private address using fdpi_ctrl:

fdpi_ctrl list status --service 11 --ip 192.168.4.20

Result:

Private subscriber IP addresses are translated into Public IP addresses.

Test 2. Configuring CGNAT and NAT 1:1 via GUI

- Creating a NAT service
- Assigning the NAT service to a subscriber
- Creating a reverse route
- Checking traffic flow
- Displaying translation information

1. Creating a NAT service (GUI)

1. Open the DPI/Services section. CGNAT tab. Create a Profile named cg_nat.

= ssg	G control 2	Adh	vertising & Ad blocking	1	Black and white lists	DDoS	protection	_	CGNAT			Mini Fire	Mini Firewall		Session policings	
Perf	rformance	Profile	s					<	Profile s	totus						
Con	nfiguration	+						æ							4	
Prot	stocol prioritization	🗅 Рто	file status				Status.		©o Stati	us						
Prio	ority for ASN		Profile			NAT type	Stotus		Brotocol	Full stotus	IR mosk	Detail	ed status	Subscr Borts in use	ibers stat	tus
Logi	3a	_	QFILTER				~		Protocol	number	IP IIIQAK		Porto	Porterinoso	0000	
Sub	bscribers and services		D contraction			11	Disabled	0	~	QFILTER	QFI	Q.FILTER	Q.FILTER	Q.FILTER		
Serv	rvices		Description *		cg_not	CONAT	Disabled	0	LIDE	0	0x0	64	4128708	0		09
Torit	iff plans		Туре		CGNAT	CGNAT	Disabled	0								
Adv	v control	• 2	NAT IP pool *		10.10.10.0/26	CGNAT	Enabled	0								
Hot	tSpot															
PCR	RF control	/														
C QoE	Eanalytics	/				_										
∩ vae	Colourd services	,	TCP sessions		2000	_										
	9 CIULU 301 1003		UDP sessions		2000	_										
😂 Adn	ministrator	·			Sancer Save											
> Har	rdware SSH terminal	/														
		**	< 1 > >>			On page	100	~	** *	1 >	**			On page	100	0
rea	ate a Profile VAS Experts arch	nam	ned bi_na ≡ ×	at. E	SSG control >	Test_I	DPI-00	>	Servi	ices						
rea	Ate a Profile VAS Experts arch SSG control	nam	ned bi_na ≣ ×	at. s	Advertising & Ad	Test_1	DPI-00	> Bk	Servi ack an	ices d white li	sts					
rea	ate a Profile VAS Experts arch SSG control Performance	e nam	led bi_n ≣ ×	et. Elice Pro	SSG control > mse status: COMPLI Advertising & Ad pfiles	E Test_I	DPI-00	B	Servi	ices d white li	sts					
rea	ate a Profile VAS Experts arch SSG control Performance Configuration	e nam	led bi_na ≡ ×	et.	SSG control > mse status: COMPU Advertising & Ad ofiles	E Test_I	DPI-00	> Bld	Servi	ices d white li	sts					
rea	ate a Profile VAS Experts arch SSG control Performance Configuration	nam	ned bi_na ≡ ×	et.	SSG control > mse status: COMPLI Advertising & Ad offiles () () ()	E Test_I	DPI-OO	> Bld	Servi	ices d white li	sts					
sec	Ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritiza Priority for ASN	e nam	ned bi_na ≡ ×	Lice	SSG control > Inse status: COMPLI Advertising & Ad offiles © © Profile status Profile	E Test_I	DPI-00	Bik	Servi	ices d white li	sts		- TAN			
sec	ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritizo Priority for ASN	e nam	ned bi_na ≣ ×	et. s lice Pro +	SSG control > anse status: COMPLI Advertising & Ad ofiles () () () () () () () () () () () () () () (E Test_I	DPI-00 E	Bk	Servi	ices d white li	sts	,	TAI			
rea	ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritizo Priority for ASN Logs	e nam	ned bi_na ≡ ×	Lice Pro	Advertising & Ad ofiles Profile status Q.FELTE	E Test_I	DPI-00 E	Bik	Servi	ices d white li	sts		NA1			
sec	Ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritizo Priority for ASN Logs	tion	ned bi_na	et. Lies Pro	Advertising & Ad ofiles Profile status Profile Profile	Test_1	DPI-00 E	B	Servi	ices d white li	sts		NAT 1			
	Ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritizo Priority for ASN Logs Subscribers and s	tion	ed bi_n	et. s Lice Pro Pro	SSG control > inse status: COMPLI Advertising & Ad ofiles	Test_I	DPI-00 E	Blo	Servi	ices d white li	sts		441			
Seco	ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritiza Priority for ASN Logs Subscribers and s Services	tion	ed bi_n	at. s Lice Pro + D	SSG control > inse status: COMPLI Advertising & Ad ofiles Profile status Profile C C CNV Descripti	Test_I	DPI-00 E	> Bk	Servi	ices d white li	sts		441 14			
Seco	ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritizo Priority for ASN Logs Subscribers and s Services	tion	ed bi_n	at. s Lice + D	SSG control > mase status: COMPLI Advertising & Ad ofiles Profile status Profile C CGN C CGN C CGN C Type	Test_I	DPI-OO E	> Bk	Servi ack an	ices d white li	sts	~	NAT 11 CG			
Seco	ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritizo Priority for ASN Logs Subscribers and s Services Tariff plans	tion	ed bi_n	at. s Lice + D	SSG control > mase status: COMPLI Advertising & Ad offiles	Test_I	DPI-00 E	> Bk	Servi	d white ii	sts	~ ~	NAT 11 CG			
rea Sec	ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritizo Priority for ASN Logs Subscribers and s Services Tariff plans	tion	ed bi_n	at. Lies Pro + D 0 0 0	SSG control > mase status: COMPLI Advertising & Ad offiles	Test_1	DPI-00	> Bk	Servi ack an	ices d white li 69.0/24	sts	~				
sed	ate a Profile VAS Experts arch SSG control Performance Canfiguration Protocol prioritiza Priority for ASN Logs Subscribers and s Services Tariff plans Adv control	tion	ed bi_n	at.	SSG control > mase status: COMPLI Advertising & Ad offiles	TTE, REMAIN 2	DPI-00	> Bk	Servi ack an hat	ices d white li 69.0/24	sts	~				
sed	ate a Profile VAS Experts arch SSG control Performance Canfiguration Protocol prioritiza Priority for ASN Logs Subscribers and s Services Tariff plans Adv control HotSpot	e nam	ed bi_n	at. : : : : : : : : : : : : :	SSG control > anse status: COMPLI Advertising & Ad offiles	Test_ TE, REMAIN 2 I blocking	DPI-00	> Bk	Servi ack an hat	ices d white li 69.0/24	sts	~	11 CG CG CG			
rea Sec	ate a Profile VAS Experts arch SSG control Performance Configuration Protocol prioritiza Priority for ASN Logs Subscribers and a Services Tariff plans Adv control HotSpot	tion	ed bi_n	at. : : : : : : : : : : : : :	SSG control > anse status: COMPLI Advertising & Ad offiles	E Test_ TI, REMAIN 2 I blocking I blocking	DPI-00 E	> Bk bi_r 1:1	Servi ack an nat	ices d white li 69.0/24	sts	~				

3. Then activate the service on the SSG by clicking the Play button. The status will change to "enabled".



2. Assigning the NAT service to a subscriber (GUI)

In the same section "DPI/Services", CGNAT tab.

In the right column "Subscribers", add a subscriber, select the "Unbound" type, enter the subscriber's IP, select service 11 "CGNAT" or "NAT 1:1", check the box "Yes" to enable, select the profile, click "Apply" and "Save".

l		Profile	Ping	Authorization	L2-props					
1	8	Profile	_							
l	в	ind type	Without bind		~	Session				
ł	lc	lentity type	Login	~						
l	L	ogin *	100.64.0.1							
	00	Services				9(
at	Id	Service		Enabled	Profile	List of s				
	4	Black list		🗆 No	~	Lo				
ist	Б	White list		🗆 No	~	0				
ho	9	Netflow stats		🗆 No		2 10				
isc	11	CGNAT		🗹 Yes	cg_nat ~					
ist	13	Mini Firewall		No No		34				
ha	\$	Tariff			cg_nat	Ŭ0				
l						26				
l	Т	ariff			Test	1				
l				Close	nat_1 (Disabled)	d n/				
l					test_nat (Disabled)	g wi				
					cg_nat					
					bi_nat (Disabled)					
						_				

To route reverse traffic to the NAT pool towards the subscribers, it will be necessary to create a route to the NAT pool on the router after the SSG and make this route known to the other routers in the network. The process is the same as in Test 1. The steps and commands do not change.

3. Creating a reverse route (GUI)

4. Checking traffic flow and interface orientation (GUI)

In the GUI, navigate to DPI > Statistics > NAT Statistics

	VAS Experts	=	SSG control > I Test_DPI-00] > Performance)
s	earch	×		0	Inline	Statistics	NAT	statistics			
8	55G control	^	Pro	Top	Devices					>	
	Performance		oessor	20 pro	Device		Stotus	Down		up	
	Configuration		s and	00000	03:00.0 - 04:00.0						
	Protocol prioritization		n 0:00.0 US count=0, last n/a (0 ticks)		count=1, lost 2024/11/26 12:23:23, -340:29:14.033 (5878558875562080 ticks	1					
	Priority for ASN		2		04:00.0		UP	count=0, last n/a (0 ticks)		count=1, lost 2024/11/26 12:23:23, -340:29:13.967 (5878559028161376 ticks)	

Check the orientation of the SSG interfaces as shown in Test 1.

5. Displaying translation information (GUI)

In the GUI, navigate to DPI > Statistics > NAT Statistics

Check the number of active sessions and the assigned public address for each private address.

Test 3. Configuring NAT log export to external collector and locally to file

1. Exporting NAT log to external collector

```
fdpi_ctrl log set nat --export-collector-ip 10.10.10.2 --export-collector-
port 514
```

To export logs, specify the IP address and port of the external collector.

2. Exporting NAT log locally

fdpi_ctrl log set nat --export-local-file /var/log/nat.log

To export logs locally, specify the desired file path.



Additional information on NAT log management: You can use the SSG's built-in options to filter, search, and manage the NAT logs. You can also configure automatic log rotation and archiving.