

Содержание

4 3

4

Check for errors when transferring to clickstream

```
tail -100 /var/log/dpi/fastdpi_alert.log|grep ERROR
```

If you have the following errors:

```
[ERROR  ][2015/07/20-20:26:48:307378][0x7fd749eac700] IPFIX :  
udp:10.0.251.7:1500 :  
    Error socket send to collector, rc=-1, errno=111 : Connection refused  
[ERROR  ][2015/07/20-20:26:48:434784][0x7fd749eac700] IPFIX :  
udp:10.0.251.7:1500 :  
    Error socket send to collector ( repeat error 1 ), now ok.
```

1. check the cache server availability from the DPI side
2. check the ip address (if it has been changed) in the CACHE server configuration
/var/cache/nginx/cs/.cs/cs.conf. If the IP address is changed you will need to stop and restart the CACHE server - [More detail about CACHE server configuration](#)