## Содержание

Configuring the platform	1	3
--------------------------	---	---

## **Configuring the platform**

To make it possible for the DPI platform to receive SM control commands, one has to specify the following settings in its configuration file /etc/dpi/fastdpi.conf:

The listening port number:

ctrl\_port=29000

The network interface name:

ctrl\_dev=eth0