

Содержание

3 Installation 3

3 Installation



Before installing or upgrading, check your Internet connection. Make shure you run scripts under the root or using sudo.



Check if the time and time zone are set correctly on the server. Correct and restart the server if necessary.



Do not disable the standard firewall-cmd. The installation script uses it for self-configuration.

For automatically installation or upgrading follow these steps:

1. Execute [fastor-rpm_install.sh](#) script.

```
source <(curl https://vasexperts.ru/install/fastor-rpm_install.sh)
```

It will cause the installation of the following packages: ipfixreceiver, clickhouse, fastor. All of them will be automatically configured according to the defaults.

2. Restart your ssh terminal. You need to make command aliases available.
3. Run the command

```
fastor-db-scheme
```

The database schema will be updated.



Do not forget to execute

```
fastor-db-scheme
```

after installation. This insures cases when the schema does not have time to update as a result of a long restart of the database.