

Содержание

- GTP Tunneling Protocol Settings 3
 - Section "fast-epdg.tunnel.pgw" 3
 - Section "fast-epdg.tunnel.pgw.gtp" 3
 - Section "fast-epdg.tunnel.pgw.gtp.gtp-server-name-n" 4
 - Section "fast-epdg.tunnel.pgw.gtp.gtp-server-name-n.gtp-c" 6
 - Section "fast-epdg.tunnel.pgw.gtp.gtp-server-name-n.gtp-u" 8

GTP Tunneling Protocol Settings

Section "fast-epdg.tunnel.pgw"

Parameter	Description	Value
gtp {}	GTP protocol settings	

Template:

```
fast-epdg {
  tunnel {
    iface =
    pdn =
    pgw {
      gtp {}
    }
  }
}
```

Example:

```
fast-epdg {
  tunnel {
    iface = epdg
    pdn = ipv4
    pgw {
      gtp {}
    }
  }
}
```

Section "fast-epdg.tunnel.pgw.gtp"

Parameter	Description	Value
mcc	Operator's MCC	XXX
mnc	Operator's MNC	YYY
realm	Served realm	epc.mncYYY.mccXXX.3gppnetwork.org
gtp-server-name-1 {}	GTP server settings #1	
gtp-server-name-2 {}	GTP server settings #2	
gtp-server-name-n {}	GTP server settings #n	

Template:

```
fast-epdg {
  tunnel {
    iface =
    pdn =
```

```

pgw {
    gtp {
        mcc =
        mnc =
        tac =
        cid =
        enbid =
        realm =
        gtp-server-name-1 {}
        gtp-server-name-2 {}
        gtp-server-name-n {}
    }
}

```

Example:

```

fast-epdg {
    tunnel {
        iface = epdg
        pdn = ipv4
        pgw {
            gtp {
                mcc =
                mnc =
                tac =
                cid =
                enbid =
                realm =
                gtp-server-name-1 {}
                gtp-server-name-2 {}
                gtp-server-name-n {}
            }
        }
    }
}

```

Section "fast-epdg.tunnel.pgw.gtp.gtp-server-name-n"

Parameter	Description	Value
apn	Served APN	ims
priority	Server priority	0-100
devname	Tunneling device	[tun][gtp]
subnet	APN subnet	IPv4: x.x.x.x/m, where x — a decimal number from 0 to 255, m — the subnet mask, a decimal number from 0 to 32 IPv6: y:y:y:y:y:y:y/n, where y — a hexadecimal number from 0000 to FFFF, n — the subnet mask, a decimal number from 0 to 128

Parameter	Description	Value
qos {}	Default bearer QoS settings	
gtp-c {}	GTP-C settings	
gtp-u {}	GTP-U settings	

Template:

```

fast-epdg {
  tunnel {
    iface =
    pdn =
    pgw {
      gtp {
        mcc =
        mnc =
        tac =
        cid =
        enbid =
        realm =
        gtp-server-name-1 {
          apn =
          priority =
          devname =
          subnet =
          gtp-c {}
          gtp-u {}
        }
        gtp-server-name-2 {
          apn =
          priority =
          devname =
          subnet =
          gtp-c {}
          gtp-u {}
        }
      }
    }
  }
}

```

Example:

```

fast-epdg {
  tunnel {
    iface = epdg
    pdn = ipv4
    pgw {
      gtp {
        mcc =
        mnc =

```



```

        realm =
        gtp-server-name-1 {
            apn =
            priority =
            devname =
            subnet =
            gtp-c {
                local =
                remote =
            }
            gtp-u {}
        }
    }
}

```

Example:

```

fast-epdg {
    tunnel {
        iface = epdg
        pdn = ipv4
        pgw {
            gtp {
                mcc =
                mnc =
                tac =
                cid =
                enbid =
                realm =
                gtp-server-name-1 {
                    apn = ims
                    priority = 50
                    devname = tun0
                    subnet = 10.1.0.0/16,2001:10::0/48
                    gtp-c {
                        local = 192.168.1.1,2001:1::1
                        remote = 192.168.2.1,2001:2::1
                    }
                    gtp-u {}
                }
            }
        }
    }
}

```

Section "fast-epdg.tunnel.pgw.gtp.gtp-server-name-n.gtp-u"

Parameter	Description	Value
local	GTP-U client address	IPv4: x.x.x.x, where x — a decimal number from 0 to 255, IPv6: y:y:y:y:y:y:y:y, where y — a hexadecimal number from 0000 to FFFF,
remote	GTP-U server address	IPv4: x.x.x.x, where x — a decimal number from 0 to 255, IPv6: y:y:y:y:y:y:y:y, where y — a hexadecimal number from 0000 to FFFF,

Template:

```
fast-epdg {
  tunnel {
    iface =
    pdn =
    pgw {
      gtp {
        mcc =
        mnc =
        tac =
        cid =
        enbid =
        realm =
        gtp-server-name-1 {
          apn =
          priority =
          devname =
          devmode =
          subnet =
          qos {
            qci =
            mbr_ul =
            mbr_dl =
            gbr_ul =
            gbr_dl =
          }
          gtp-c {
            local =
            remote =
          }
          gtp-u {
            local =
            remote =
          }
        }
      }
    }
  }
}
```



```
}  
}  
}
```

Example:

```
fast-epdg {  
    tunnel {  
        iface = epdg  
        pdn = ipv4  
        pgw {  
            gtp {  
                mcc =  
                mnc =  
                tac =  
                cid =  
                enbid =  
                realm =  
                gtp-server-name-1 {  
                    apn = ims  
                    priority = 50  
                    devname = tun0  
                    devmode =  
                    subnet = 10.1.0.0/16,2001:10::0/48  
                    qos {  
                        qci = 5  
                        mbr_ul = 128  
                        mbr_dl = 128  
                        gbr_ul = 128  
                        gbr_dl = 128  
                    }  
                    gtp-c {  
                        local = 192.168.1.1,2001:1::1  
                        remote = 192.168.2.1,2001:2::1  
                    }  
                    gtp-u {  
                        local = 192.168.1.1,2001:1::1  
                        remote = 192.168.2.1,2001:2::1  
                    }  
                }  
            }  
        }  
    }  
}
```