

Содержание

1. Do not upgrade the OS kernel. Other components are OK to upgrade:

```
yum --exclude=kernel* update
```

2. Upgrade drivers on the running system:

```
yum install dna-ixgbe fastdpi dpiutils
```

3. Add to the configuration file /etc/dpi/fastdpi.conf the parameter scale_factor
4. Prepare a script to upgrade drivers "on the fly" in file dpiupdate.sh:

```
service fastdpi stop  
rmmod ixgbe  
modprobe ixgbe  
service fastdpi start
```

And execute it:

```
chmod +x dpiupdate.sh  
nohup ./dpiupdate.sh&
```

5. Check that everything works¹⁾

¹⁾

If it does not: reboot the computer, or read this information "[Troubleshooting](#)", or contact the tech support