

Содержание

In order to filter a traffic of some particular subscribers, or exclude filtering of transit traffic, or provide filtering to other operators as a service - you will need to activate Subscriber Management to control this service. Please add configuration parameter to the file `/etc/dpi/fastdpi.conf` to activate:

```
black_list_sm=1
```

As a result, this service is configured on level of individual subscribers by [fdpi_ctrl](#).

Instruction format:

```
fdpi_ctrl command --service 4 [IP_list]
```

You can find more details on the instruction syntax and IP specification methods here: [Control instructions](#)

Examples:

Activate the service for all subscribers and switch filtering off for an administrator:

```
fdpi_ctrl load --service 4 --cidr 192.168.0.0/24  
fdpi_ctrl del --service 4 --ip 192.168.0.1
```

Enable the service for an independent system AS50538:

```
fdpi_ctrl load --service 4 --cidr 37.110.240.0/21 --cidr 109.235.216.0/21
```