


# Table of Contents




### A typical connection diagram for Supermicro based platform:



IPMI - is an integrated control and monitoring interface of Supermicro platform

[IPMI configuration](#)

### A typical connection diagram for Dell r620 based platform:



iDRAC - is an integrated Dell Remote Access Controller: control interface.

The external access network interface sends outbound requests to a cloud platform, netflow traffic transmission and SSH access for tech support, if required. You have to assign the IP address on initial install:

[IP address assignment](#)

IN1,2,3 - are [dna0;dna2;dna4](#) respectively. They connect the platform to internal operator's network.  
OUT1,2,3 - are [dna1;dna3;dna5](#) respectively. They connect the platform to external network (Internet).