

Содержание

2 FastPCRF parameters 3

2 FastPCRF parameters

Command-line options and Configuration parameter classes of the FastPCRF component is specified in the `/etc/dpi/fastpcrf.conf` file.

The following command-line options and parameter classes are supported:

- [FastPCRF command-line options](#)
- [Common FastPCRF parameters](#)
- [Parameters specifying connection between FastPCRF and FastDPI](#)
- [FastPCRF settings for radius servers](#)
- [Parameters of CoA notifications being sent to FastDPI servers](#)