# **Table of Contents**

HotSpot Section Management	3
Common Settings	4
View Settings	5
Localization Settings	5
Auth and Click-Wrap Settings	6
WiFi Authorization Settings	6
Click-Wrap Settings	7
Services Settings	8
Tariffs Settings	8
DHCP configuration	9
Logs	9
Configuration Management	10

# **HotSpot Section Management**

Wi-Fi HotSpot is a system that provides public internet access after user authorization and identification via a phone number or SMS.

User Authorization Process:

- 1. The user (not yet a subscriber) connects to the public Wi-Fi hotspot.
- 2. The DHCP server assigns them an internal IP address, and the system triggers internet blocking through the "Whitelist" service, which restricts access to everything except the authorization page. Connection speed limitations are also applied.
- 3. The client's device automatically redirects to the authorization page, where they need to enter their phone number and choose a verification method via SMS or a call to the provided number.
- 4. After authorization, depending on the agreement terms, the system removes the restrictive policing and the "Whitelist" service.

If DPI is used, a subscriber profile is created with a login (phone number) and assigned IP. The profile becomes active, granting the subscriber internet access with the necessary policies and services. When the "Session Lifetime" parameter expires, deauthorization occurs. DPI removes all services and policing, deletes the "login-IP" link, and reactivates the "Whitelist" service with access restrictions, requiring the subscriber to reauthorize.

If a billing system is used, it receives a request with the IP and phone number, then applies settings according to the billing parameters and timeouts.

WiFi HotSpot configuration is carried out in the GUI section SSG Control  $\rightarrow$  HotSpot.



This section was introduced in GUI v2.6.6. The module description interacting with this section is available via this link.

The section contains tabs:

- Common Settings
- View Settings
- Localization Settings
- Auth and Click-Wrap Settings
- Services Settings
- Tariffs Settings
- DHCP configuration
- Logs

VAS Experts	≡	SSG control > 目 Test_DPI-00 ; > HotSpot		🕀 🔊 🖓 o	B
Search	×	🖹 Save C' 8		Delete configurat	tion
SSG control	~	St Configuration	©© Common settings		
Dasformanon		©ª Common settings	Web server *		
Performance		View settings		Ý	( <del>†</del> )
Configuration		D Localizations settings	Captive portal URL *		
Protocol prioritization		& Auth and Click-Wrap settings			W
Priority for ASN		i≣ Services settings	Redirect URL *		1
Logs		\$ Tariffs settings	nttps://www.example.com/		_
Subscribers and services		@ DHCP configuration			
Services		👌 Logs			
Tariff plans					
Adv control					
HotSpot					
ACR PARE					
8m PCRF control	~				
QoE analytics	$\sim$				
VAS cloud services	~				
administrator	~				
>_ Hardware SSH terminal Version 2.35.30 S	~				

### **Common Settings**

1. In the "Web Server" parameter, select the HOTSPOT server linked to DPI.

If the corresponding equipment is not available, add it using the "Add New Device" button. A form for creating a new device will appear; in it, create a device with the "HOTSPOT server" type.

Common settings			
Veb server *	🖶 Hardware settings		
aptive portal URL *	Name * HOTSPOT server	Hardware type HOTSPOT server	~
edirect URL •	Host *	Port * 22	
	Login *	Auth type By password	v
	Password *		
	Sudo user		0

- 2. In the "Captive portal URL" parameter, specify the URL to which the subscriber will be redirected for network authorization. Creates/updates the Whitelist service profile with the entered URL. The profile name is hotspot\_white\_list\_profile.
- 3. In the "Redirect URL" parameter, specify the URL to which the subscriber will be redirected after successful authorization on the HotSpot portal. If the field is empty, the subscriber is redirected to https://google.com.

### **View Settings**

In this section, you can change the favicon and logo displayed on the portal page.

View settings	
Logo	
	Click to download or drag a file
Favicon	
	Click to download or drag a file

## **Localization Settings**

1. Add a language for localization settings by clicking +. Available languages list:



2. Select the added language to configure parameter values. Change values by clicking on them.

Localizations settings			
+ ~			
Language		Кеу	Value
🐹 English	Û	info_label	To activate Internet access, specify your mobile phone
		phone_label	Phone number
		wrong_phone_number	Wrong phone number
		wrong_email	Wrong email
		get_code_button	Get code
		call_button	Make call
		coll_text	Call this number for authorization
		sms_code_input_label	Code from sms
		auth_code_button	Authorize
		resend_code_button	Resend code
		success_text	Some success authorization text of any length
		click_wrap_text	Some text for click wrap
		click_wrap_checkbox	Some label for click wrap text
		click_wrap_button	Continue
		click_wrap_button_cancel	Cancel
		close_window_label	Close Window?

3. Any language can be set as the default by clicking the "Set as Default" button. By default, the first added language is set as the default.

Localizations settings	
+ 🗸	
Language	
💥 English	Û
C Türk	Û

If two or more languages are configured, the authorization page will have a button to select the language.

### Auth and Click-Wrap Settings

#### **WiFi Authorization Settings**

Wi-Fi authorization is the process of connecting to a network with user identification via a phone number or SMS.

To configure this type of authorization, select "Yes" for the "WiFi authorization enabled" parameter. All WiFi authorization settings will then appear:

1. "Session management enabled" If "Yes" is selected, subscriber creation and management (authorization and deauthorization) occur through DPI, allowing for "Session lifetime" configuration (After the session lifetime expires, HotSpot will execute a script to delete the subscriber from DPI and apply the authorization tariff and the Whitelist service to their IP address).

If "No" is selected, subscriber management occurs via the billing system or another third-party service. Here, you need to configure an HTTP request sent to the billing API, which will apply and remove the appropriate policies for the subscriber.

- 2. "Authorization type" Two options are available:
  - "By auth code" for this option, you need to configure HTTP requests to the service for sending SMS and calls. You can also enable the "Sequential Authorization" parameter — this mode allows you to select the initial authorization method, and the "Debug Mode" — enables sending the authorization code to the email specified in the phone number field to test the subscriber
  - authorization scenarios.
  - 2. "By outgoing call" for this option, configure two parameters:
    - "Outgoing call phones list" enter phone numbers separated by commas. HotSpot will randomly select a phone number to authorize the subscriber by an outgoing call.
    - "Secret key for hash generating" configure the call service to send an HTTP request about receiving an outgoing call from the subscriber to HotSpot. A hint on setting up the HotSpot API method for receiving the signal and creating a hash is available by clicking the question mark icon next to the parameter.

#### **Click-Wrap Settings**

Click-wrap displays the text of a public offer that subscribers must agree to in order to use the services.

To configure this type of authorization, select "Yes" for the "Click wrap enabled" parameter. Clickwrap settings will then appear:

1. "Session management enabled"

If "Yes" is selected, subscriber creation and management (authorization and deauthorization) occur through DPI, allowing for "Session lifetime" configuration (After the session lifetime expires, HotSpot will execute a script to delete the subscriber from DPI and apply the authorization tariff and Captive Portal service to their IP address).

If "No" is selected, subscriber management occurs via the billing system or another third-party service. Here, you need to create an HTTP request sent to the billing API, which will apply and remove the appropriate policies for the subscriber.

note

This scenario is only possible if the click-wrap works in conjunction with WiFi Authorization. If <u>only</u> the click-wrap is active, restrictions (Whitelist service) are removed upon confirmation.

The click-wrap text is configured in the "Localization Settings" section under parameters prefixed with "click\_wrap":

click_wrap_text	Some text for click wrap
click_wrap_checkbox	Some label for click wrap text
click_wrap_button	Continue
click_wrap_button_cancel	Cancel

## **Services Settings**

!

Service settings are available only when "Session management enabled" = "Yes" in the "Auth and Click-Wrap Settings" section.

This form provides settings for services available to subscribers after they authorize on the portal.

I Services settings		
Enable Advertising (service id = 2)	~	•
Enable Ad blocking (service id = 3)	~	3
Enable black list (service id = 4)	~	1
CGNAT named profile (service id = 11)	~	1
Enable Notification (service id = 50)	~	1
No		
162		

The following services are available for connection:

- 2. Advertising no profile
- 3. Ad Blocking no profile
- 4. Blacklist with or without a profile
- 11. CGNAT profile selection required
- 50. Notification no profile

### **Tariffs Settings**



Tariff settings are only available when the "Session management enabled" parameter is set to "Yes" in the "Auth and Click-Wrap Settings" section.

This form allows configuring tariff plan parameters applicable to subscribers during Wi-Fi authorization. The tariffs in the form correspond to the following names on the DPI:

- **Authorization Policing** applied at the moment of network authorization. Corresponds to the named profile wifi\_hotspot\_auth\_policing on the DPI.
- Wi-Fi Policing applied after successful authorization. Corresponds to the named profile wifi\_hotspot\_policing on the DPI. It is assigned to the subscriber after completing authorization on the portal.

Tariff	Simple form	Common form	Adv	anced form	Editor	
	On Closses					
Authorization Policing	Closs		inbo	ud	Outbo	und
Wifi Policing	0.000		1.000			
			Rate	Ceil	Rate	Ceil
	🖉 root					
	Ø 0					
	2 1					
	2					
	2 3					
	2 4					
	2 5					
	6					
	2 7					

## **DHCP** configuration

Supplementary information for connecting the DHCP server:

- 1. Configure remote ssh commands
- 2. Set up on the trigger for issuing a new IP:

For Wi-Fi authorization use this trigger:

ssh dpi\_user@dpi\_host "/var/dpiui2/add\_captive\_portal\_auth.sh <IP>"

If you need only click-wrap function use this trigger:

```
ssh dpi_user@dpi_host "/var/dpiui2/add_captive_portal_click_wrap.sh <IP>"
```

### Logs

This subsection contains log files for the interface and Click-Wrap feature. To update the list, click the "Refresh" button.

## **Configuration Management**



- 1. Save configuration
- 2. Refresh configuration
- 3. Navigate to the documentation page for the HotSpot section
- 4. Delete configuration