

Содержание

2 FastDPI server 3


2 FastDPI server

Section content:


- [Switching between DPIs](#)
- [DPI information](#)
- [Updating hot options](#)
- [Restart FastDPI](#)

Switching between DPIs

You can control only one selected device.



To switch to the section "Managing the list of devices" open the "Device_name" menu and press "Select from list".



The list (with filtration options) of available devices will be opened.


A screenshot of the VAS Experts DPI interface showing a list of available devices. The 'DPI' tab is active. A table is displayed with columns: Name, Ip, Port, and Login. The table contains two rows: 'Test stand .34' and 'Work stand .85'. A green arrow points to 'Work stand .85' with the text 'Click to select equipment'.

Name	Ip	Port	Login
Test stand .34		22	arushak
Work stand .85		22	dpisu


Clicking on a list item causes switching to the device

DPI information

For device information open the "Device_name" menu and press the "Device information".




Subwindow "Device information" containing device main characteristics will be opened




Updating hot options

When you change some options (the so-called "on-the-fly" or "hot" options) in the hardware configuration, it is not necessary to restart the fastdpi service. You can use "Updating hot options".

To update "hot" ("on-the-fly") options open the "Device_name" menu and press "Updating hot options".




You will be prompted to confirm the operation. Click Refresh.




An operation will be performed. The result will be displayed.

Restart FastDPI

If you change standard (not "on-the-fly") options you need to restart the fastdpi service.



To restart the service, open the "Device_name" menu and click "Restart fastdpi".



A restart will be performed. The result will be displayed.